






CLOSE COUPLE TOILET


Cygnet Hygiene Rim Square CCBTW - Bottom Inlet with SpaLet E-Bidet Seat AS01011




American Standard




x1



x1



x1



x1



x1



x1




x1








x1



x1




x1







1




2




3




4



5a



5b



6a


ROUGHING - IN (A)	CONNECTOR CUTOUT (B)
140-150 mm.	10 mm.
151-159 mm.	20 mm.

6b


ROUGHING - IN (A)	CONNECTOR CUTOUT (B)	ROUGHING-IN (A)	CONNECTOR CUTOUT (B)
160-170 mm.	30 mm.	211-220 mm.	80 mm.
171-180 mm.	40 mm.	221-230 mm.	90 mm.
181-190 mm.	50 mm.	?	?
191-200 mm.	60 mm.	261-270 mm.	130 mm.
201-210 mm.	70 mm.	C=116 - (A-160)	




7




8



9




10




Ø22

11




12



*Refer to full SpaLet installation instructions provided in seat box

13



14

IMPORTANT

Before turning on water supply check:

1. Cistern is installed properly
2. All moving components operate freely
3. All couplings are tightened correctly

Now fill cistern and recheck water level:

4. Check carefully for leaks
5. Test the cistern flushes

CLOSE COUPLE TOILET

Installation Manual






Cygnnet Hygiene Rim Over-height Square

Cygnnet Hygiene Rim Square


Bottom Inlet




American Standard



_____ x1




_____ x1



_____ x1




_____ x1



_____ x1




_____ x1




Option 1


_____ x1



_____ x1




Option 2







Cygnets Hygiene Rim Over-height Square




w/ normal S&C




Cygnets Hygiene Rim Square




w/ normal S&C




Cygnets Hygiene Rim Over-height Square




w/ Spalet E-bidet



Cygnets Hygiene Rim Square




w/ Spalet E-bidet







1




2.1 / 2.2




Option 2: Spalet Installation


3




4




5




ROUGHING - IN (A)	CONNECTOR CUTOUT (B)	ROUGHING - IN (A)	CONNECTOR CUTOUT (B)	ROUGHING-IN (A)	CONNECTOR CUTOUT (B)
140-149 mm.	10 mm.	160-170 mm.	30 mm.	221-230 mm.	90 mm.
150-159 mm.	20 mm.	171-180 mm.	40 mm.	231-240 mm.	100 mm.
		181-190 mm.	50 mm.	241-250 mm.	110 mm.
		191-200 mm.	60 mm.	251-260 mm.	120 mm.
		201-210 mm.	70 mm.	261-270 mm.	130 mm.
		211-220 mm.	80 mm.	C= 116 - (A-160)	












6a



6b



**7****8****9****10****11****12.1 / 12.2****13.1 / 13.2****14**

IMPORTANT

Before turning on water supply check:

1. Cistern is installed properly
2. All moving components operate freely
3. All couplings are tightened correctly

Now fill cistern and recheck water level:

4. Check carefully for leaks
5. Test the cistern flushes