

# SS316L


# Nero

## Progressive Universal Wall Basin/Bath Mixer

Body Only




Lead Free



Version:202506

### Drawing



### Specifications

#### SKU

NRUB007

#### Watermark License

WM-060073

#### Temperature Rating

Min 1°C-Max 75°C

#### Pressure Rating

Min 150kpa - Max 500kpa

### Packaging Includes

1x Mixer Body


\*Dimensions are nominal measurements only.

\*\*Only compatible with all SS316L bath / shower mixers.

# Installation Instruction For Body

## GENERAL INSTRUCTIONS:


- This product must be installed by a licensed plumber. Ensure that your plumbing installation complies with the Australian/New Zealand Standard AS/NZS 3500.
- All pipework must be thoroughly flushed prior to the installation of the mixer. In-line filters must be fitted on both hot and cold supplies to prevent foreign particles from damaging the ceramic cartridge.
- All outlets used primarily for personal hygiene must deliver water at a safe temperature in accordance with regional regulations.




1. Secure the mixer body (1) to the nogging, ensuring an installation depth of 51-68mm from the nogging to the ceramic tile.

Note: Do not remove the protective sleeve (2) from the mixer body.


2. Connect the cold and hot water supply lines and perform a leak test.
3. Drill a  $\phi 50\text{mm}$  and a  $\phi 40\text{mm}$  hole in the plasterboard for mixer body installation, and then position the plasterboard as shown in the above image.



4. Mark the protective sleeve (2) 4-7mm from the ceramic tile surface to the body.
5. Remove the self-tapping screw, washer, and protective sleeve, then cut the sleeve at the marked point.
6. Reattach the self-tapping screw, washer, and protective sleeve.




7. Waterproof the gap between the plasterboard and body.




# Installation Instruction

## For Trim Kits Only




1. Drill a  $\phi 50\text{mm}$  and a  $\phi 40\text{mm}$  hole in the ceramic tile, then position it as shown in the above diagram.
2. Undo the self-taping screw to remove the protective sleeve, and release the grub screws to remove the water testing plug.



3. Insert the O ring to the cartridge bell groove, and screw the cartridge bell onto cartridge.
4. Apply waterproof treatment to the area indicated in the diagram above.
5. Screw the dressing ring onto the cartridge bell.





6. Slide the backplate and washer onto the wall, set the spout in place, and secure it tightly using the grub screw.

7. Position the handle, tighten it with a grub screw using an Allen key, and cap the grub screw hole.

Please note: there is a washer between backplate and the spout.

### **MAINTENANCE AND CARE:**

- Regularly check the mixer and connections for signs of wear or leaks.
- Clean the tap with mild soapy water to maintain its appearance, avoiding harsh chemicals and abrasive materials that may damage the finish.

### **FINAL INSPECTION:**

- Ensure the tap operates smoothly and that there are no leaks at the connections.
- Clean the area and the newly installed tap with a soft cloth to remove any installation residues.

Nero

